



Quality, innovation and customer care, it's in our nature



Installation manual Dedicated PART 2/2

MANUFACTURER	Hyundai
TYPE	i30
ENGINE DISPLACEMENT	1600
NUMBER OF VALVES	16
ENGINE CODE / NUMBER	G4FD
VEHICLE CATEGORIES	M
TRANSMISSION	MT
VERSION	Direct LiquiMax-2.0
PETROL ECU MANUFACTURER / CODE	Kefico MED 17.9.8 2BELO
HIGH PRESSURE PETROL PUMP	BOSCH-HDP-5-PE / 0261520.(081)/(082)
HIGH PRESSURE PETROL INJECTOR	BOSCH-HDEV-5-1 / 0261500.(100)/(101)
MODEL YEAR:	2013
SYSTEM APPROVAL NUMBER (R115)	E4-115R-000004 / DLM-LPG 01
LOCATION SYSTEM STICKER	right side, centre door post
ENGINE SET NUMBER	349/070007/A
MANUAL NUMBER	076/0909500
DATE	2014-04-03



TABLE OF CONTENTS

General instructions	2
Required equipment / tools / materials for installing a complete system	3
Vehicle check.....	3
Tightening moments.....	4
Direct LiquiMax	5
Overview Direct LiquiMax	6
Direct LiquiMax parts / approval numbers	7
Mounting and connection points	8
Removal of the Bosch High Pressure Pump.....	9
Installation of the Bosch High Pressure Pump	10
High pressure pump installation.....	11
High pressure pump return	12
Preparation boost pump	13
Installation boost pump.	14
Connection of the fuel hose to the boost pump	15
Fuel Supply Unit.....	16
Mounting the FSU and FRU	17
Fuel Return Unit.....	18
LPG / petrol fuel lines.....	19
Supply hose – Return hose – Tank wiring.....	20
Hose routing.....	21
Hose routing.....	22
Mounting the AFC	23
Wiring AFC / relay location.....	24
Wiring	25
Engine cover	26
Mounting the fuel selection switch	27
Wiring inside	28
Electrical connections.....	29
Electrical connections.....	30
Circuit diagram MANUAL transmission.....	31
Electrical connections MANUAL transmission.....	32
Electrical connections.....	33
Electrical connections.....	34
Checklist after installation.....	35

FOR EXPLANATION AND CIRCUIT DIAGRAMS SEE : INSTALLATION MANUAL GENERAL PART 1 / 2



General instructions

- The installation of the system shall be done in accordance with the installation manual provided by Prins Autogassystemen.
- This manual is based on Dutch regulations, always install the system in accordance to the local regulations.
- For an optimal functioning of the Direct LiquiMax system, maintain a clean and organized work environment during installation and maintenance to prevent pollution of the LPG components.
- Always download the "general manual 1/2 " from our website for basic instructions and diagrams.
- Always disconnect the battery when installing the LPG system. Make sure the ignition key is outside the car.
Be aware of central door locking, radio / telephone memory code, alarm system.
- Wear safety goggles when working on petrol filled system / connections (pressurized petrol)
- Do not place the main fuse into the fuse holder before having completed the installation of the system.
- The AFC has to be activated by means of the Prins diagnosis software.
- Never disconnect the AFC connector, unless you have removed the main fuse.
- When installing the wiring harness, ensure that it does not run near any of the ignition components.

Solder and insulate all electrical connections.

The wires in the loom are provided with numbers and text. The text on the wire explains the function of the wire. The wire harness is not model specific, therefore it may be necessary to adjust the length of the wires.

Ensure maximum care is taken when connecting wiring.

Make professional joints using solder and shrink sleeve. Do not stretch the wiring harness.

- No component of the LPG-system shall be located within 100 mm of the exhaust or similar heat source, unless such components are adequately shielded against heat.
- If holes have to be drilled (wear safety glasses) for installing brackets, etc., the drilled holes must always be treated with an anti-corrosion agent, after the chips have been removed (especially when mounting a exterior filler into body work).
- After having completed the installation, check the whole system for LPG leakage; use a LPG leak detection device. Also check for leak of engine coolant, petrol and air.
- Fitting and maintenance is only allowed by Prins Autogassystemen selected LPG engineers.
- Failure to follow the instructions in this manual can result in a poor or non-working LPG installation or a dangerous situation.
- For maintenance instructions and filter registration see owner manual.
- Prins Autogassystemen is not responsible for any damages to people or objects as a result of changes to Prins products.
- Check our website regularly for diagrams, certificates, updates, info-bulletins and product information.

Register (warranty card) the system on the Prins warranty portal .



Required equipment / tools / materials for installing a complete system

- Complete workshop toolbox (wrenches, screwdrivers, cutters, pliers, ratchet, sockets)
- Car lift
- Portable computer : operating on Windows 98,W2000 or XP.
 - Internal memory : 16 Mb or more
 - Memory HD space : 5MB
 - Screen : 256 colours, advise colours 16 bits or more
 - Com port : 1 free COM port 1 or COM port 2 with a 9 or 25 pins connector
- Vehicle fuel system scan tool or OBD scan tool Prins (part nr. 099/99928)
- Exhaust gas analyser
- Multimeter
- Oscilloscope
- Prins diagnostic software
- Prins serial interface
- Torque wrench (10Nm)
- Torque wrench (200-250Nm)
- Portable light
- Assortment drill bits 4 to 12 mm
- Assortment cutters (ø 20, 30, 50, 70 mm)
- Portable drill or pneumatic drill
- Thread cutting device (male M6x1, M8x1, M10x1)
- Socket 46mm
- Air gun
- Vacuum cleaner
- Safety goggles
- Hot air gun
- Soldering iron, soldering tin
- Wire-stripping pliers
- Adhesive tape
- Adhesive sealant
- Thread locking compound
- Anti-corrosion agent / black body coating
- Gas leak detection device or foam leak spray
- Shrink sleeves
- Engine coolant

Vehicle check

- Check the vehicle drivability on petrol
- Check the fuel system for error codes (scan tool)
- Check if the catalytic converter is in good condition (exhaust gas analyzer)
- Check the condition of the ignition system (spark plugs, cables, coil)



Tightening moments

	Nm	SW
M 4 x 0,7	3,3	7
M 5 x 0,8	6,5	8
M 6 x 1,0	11,3	10
M 7 x 1,0	14,5	11
M 8 x 1	24,5	13
M 8 x 1,25	27,3	13
M 10 x 1	52	15-16-17
M 10 x 1,5	54	15-16-17
(filtered)Banjo bolt	10	14
Supply line connection	15	13
Fuel module Allen bolts	20	7
Filler hose connection	50	22

EXPLANATION OF SYMBOLS :




= IMPORTANT,
CAUTION



= WEAR SAFETY GOGGLES




Direct LiquiMax



Overview Direct LiquiMax

overview Direct Liqui Max




Direct LiquiMax parts / approval numbers

 1st generation  2nd generation	 1st generation  2nd generation
Fuel Supply Unit : E4-67R-010269	Fuel Return Unit : E4-67R-010270 Pressure Sensor : E4-67R-010051
	
Boost pump	High Pressure Pump : E4-67R-010266 High Pressure Rail : E4-67R-010267 High Pressure Injectors : E4-67R-010309
	 XD-3 LPG  XD-4 LPG
AFC : E4-67R-010098 E4-10R-030507	Fuel lines series XD : E4-67R-010247 XD3 E4-67R-010247 XD4



Mounting and connection points



A : High pressure petrol pump	L : R115 Approval sticker
B : Fuel Supply Unit : FSU	M : Grommet
C : Fuel Return Unit : FRU	N : Gas system fuses
D : Boost pump	P : T-ect
E : AFC	Q : Low pressure petrol sensor signal
F : Boost pump relay	R : MAP, Analog 3
G : Tank relay	S : Analog 2
H : Petrol ECU	T : Analog 4
I : Engine speed signal RPM	V : Digital input 3
J : “+” ignition	W : Wake-Up
K : High pressure petrol sensor signal	X : Digital input



L: i.a.:
R115 approval sticker :
Right side centre door post



Removal of the Bosch High Pressure Pump

-REMOVAL-


-WARNING-

In case of removing the high pressure fuel pump, high pressure fuel pipe, delivery pipe, there may be injury caused by leakage of the high pressure fuel.
Don't do any repair work right after engine stops (HOT engine).

- Turn the ignition switch OFF and disconnect the battery negative (-) cable.
- Wear safety goggles.
- Disconnect the fuel pressure regulator valve connector
- Disconnect the High Pressure fuel feed pipe (B)
- Remove the Low Pressure fuel pipe / hose (A).
- Remove the installation bolts (E), and then remove the high pressure fuel pump from the cylinder head assembly.

CAUTION:

Unscrew in turn the two bolts in small steps (0.5 turns). In case of fully unscrewing one of the two bolts with the other bolt installed, the housing surface of the cylinder head may break because of tension of the pump spring.



CAREFULLY store the removed petrol pump. Make sure no pollution can come into the pump.




Installation of the Bosch High Pressure Pump

INSTALLATION:

Before installing the high pressure fuel pump, position the roller tappet (**B&C**) in the lowest position by rotating the crankshaft. Otherwise the installation bolts may be broken because of tension of the pump spring.

Apply engine oil to the O-ring (**A**) of the high pressure fuel pump, the roller tappet (**B**), and the protrusion (**C**). (roller tappet, only if removed from cylinder head)
Also apply engine oil to the groove on the location where the protrusion (**C**) is installed.



Installation bolts:

When tightening the installation bolts of the high pressure fuel pump, tighten and turn the bolts in small step (0.5 turns) after tightening them with hand-screwed torque.

High pressure fuel pump installation bolt: 12.8 ~ 14.7 N.m

Fuel pipe:

First hand-tighten the nut(s) fully until they are not fastened any more in order to have them inserted in place and then completely tighten to the specified torque using a torque wrench.
If not tightening the bolts or nuts in a straight line with the mating bolt holes or fittings, it may cause a fuel leak due to broken threads.

High pressure fuel pipe installation nut: 26.5 ~ 32.4 N.m

Installation is reverse of removal.



High pressure pump installation




Replace the high pressure pump for the adapted high pressure pump.
(Follow the workshop manual of the car)




High pressure pump return

Replace the high pressure pump for the adapted high pressure pump.
(Follow the workshop manual of the car)




Preparation boost pump



Replace connector and valve



Drill up connector bracket



Remove hose and bracket



Re-locate wiring



install a spring washer and M6x18 nut



Install new longer hose to valve



Installation boost pump.



Filtered banjo

regular banjo





Connection of the fuel hose to the boost pump.

Connect the fuel hoses with an adapter to the boost pump.





Fuel Supply Unit






Black filtered banjo will only be used on inlet connections !



Mounting the FSU and FRU



Fuel Return Unit




LPG / petrol fuel lines



Hose	from	to	Length (cm)
XD-4	Adapter original petrol hose	Petrol boost pump	40
XD-3	Fuel supply unit	High pressure petrol pump	25
XD-3	Petrol boost pump	Fuel supply unit	55
XD-3	Fuel return unit	High pressure petrol pump	50
	Fuel return unit	High pressure petrol rail	n.a.



Filtered banjo: (FSU supply inlets / boost pump inlet : black filtered banjo) :




181/300009/A




Supply hose – Return hose – Tank wiring


Protect the supply- and return hose together with tank-wiring using the Ø16 split tube.
Mount the "hose assembly" with clamps, with a maximum distance of 40cm.



Hose routing



Old and new type FRU :



Hose routing



Mounting the AFC



AFC





Relay






Fuses



Wiring AFC / relay location



Wiring



Engine cover



Remove foam for boost pump



Mounting the fuel selection switch



Wiring inside : **switch / CAN / Wake-up**


Switch-ring : optional



Wiring inside




Driver room

3-pole micro connector		
66 Ground fuel switch	Brown	Connect the 3-pole connector to the Prins fuel selection switch.
3 +12V fuel switch	Red	
49 LIN fuel switch	yellow	
51 CAN-High	Blue-yellow	EOBD connector pin 6, Green or White
70 CAN-Low	Blue	EOBD connector pin 14, Orange or Black
		
121 Wake-up switch	Red-grey	Wire colour : White Wire location : left side dashboard, fuse box



Electrical connections

Check and measure the wiring in case of changes in the cars wiring colours.
Insulate not used wires.

Wire number / code	Wire colour	Connection
1-32 MAIN GND ecu MAIN GROUND SENSE MAIN GND pump driver MAIN GND boost pump	brown	Connect to the '-' of the battery (-31) ; use a ring terminal. Wire location : left side suspension
4 – 13 – 44 +12V BATT sense +12V BATT fused +12V BATT boost pump +12V BATT pump driver	red	Connect to the '+' of the battery (+30) ; use a ring terminal. Do not place the fuse in the holder before having completed the installation of the LPG system. Wire location : fuse box
		



Electrical connections

Check and measure the wiring in case of changes in the cars wiring colours.
Insulate not used wires.

<i>Wire number / code</i>	<i>Wire colour</i>	<i>Connection</i>
23 Digital Simulation	Green-red	insulate
115 Digital input 4	Yellow-red	insulate
119 Digital input 2	Yellow-grey	insulate
6 Lambda1 WB	Orange	insulate
42 Lambda2 WB 10KΩ	Orange-white	insulate
97 Digital input 5	Yellow-orange	insulate
113 Digital input 6	Yellow-purple	Insulate
10 Simulation 2	Green-black	insulate

3-pole connector		
27 +5V sensor	Red	insulate
37 C ground	Brown	insulate
20 Analog 3 MAP	Blue	insulate




Circuit diagram **MANUAL** transmission

MFI Control System (G4FD : GAMMA 1.6L GDI M/T) (2)

SD313-10


Full Circuit Diagrams



Electrical connections **MANUAL** transmission

Check and measure the wiring in case of changes in the cars wiring colours.
Insulate not used wires.

Wire number / code	Wire colour	Connection
17 Analog 2	Blue-black	For measuring the MAP sensor signal. Wire colour : white-black Wire location : Petrol ECU, T94, pin 80
8 RPM	Purple-white	For measuring the engine speed signal. Wire colour : white Wire location : Petrol ECU, T94, pin 65
15 T-ect	Grey	For measuring the engine coolant temperature. Wire colour : orange Wire location : Petrol ECU, T60 , pin 23
18 Analog 1 25 Simulation 1	Blue-red Green-grey	High pressure petrol sensor interruption Sensor side. ECU side. Wire colour : orange Wire location : Petrol ECU, T94, pin 58
117 Digital input 3	Yellow-black	High pressure petrol sensor supply Wire colour :yellow Wire location : Petrol ECU, T94, pin 20
19 Analog 4	Blue-white	High pressure petrol sensor ground Wire colour : pink Wire location : Petrol ECU, T94, pin 76
7 +12V IGNITION	Grey - white	Make a connection to ignition + / contact + (+15). Do not place the fuse in the holder before having completed the installation of the LPG system. Wire colour : pink Wire location : Petrol ECU, T94, pin 29



Electrical connections

**Check and measure the wiring in case of changes in the cars wiring colours.
Insulate not used wires.**

Engine room

Wire number / code	Wire colour	Connection
<i>3-pole connector</i>		Connect the 3-pole connector to the Psys sensor positioned into the Fuel Return Unit.
35 C Ground pin A	Brown	Sensor wire pin A
9 +5V sensor pin B	Red	Sensor wire pin B
16 Psys pin C	Green	Sensor wire pin C
14 T-LPG	Grey	Not used, insulate.
<i>2-pole connector Boost Pump</i>	Red	Connect the 2-pole connector to the lock-off valve of the Boost Pump.
106 + Lock-off Boost Pump	White-yellow	
98 Ground lock-off		
<i>2-pole connector FSU</i>	Red	Connect the 2-pole connector to the lock-off valve of the Fuel Supply Unit
108 + Lock-off FSU	Pink-yellow	
100 Ground lock off		
<i>2-pole connector FRU</i>	Red	Connect the 2-pole connector to the lock-off valve of the Fuel Return Unit
90 + Lock-off FRU	Blue-yellow	
82 Ground lock off		
<i>4-pole diagnose connector</i>		Diagnose connector for service / diagnosis
46 Service TxD	Grey	Connector pin 1
65 Service RxD	Grey	Connector pin 2
68 C ground	Brown	Connector pin 4
<i>Boost pump relay</i>		
107 + relay boost pump	Red	Pin 86 of the boost pump relay
99 GND relay boost pump	Green-yellow	Pin 85 of the boost pump relay
+12V fused BATT	Red	Pin 30 of the boost pump relay
+12V Boost pump	Red	Pin 87 of the boost pump relay

Driver room

<i>3-pole micro connector</i>		
66 Ground fuel switch	Brown	Connect the 3-pole connector to the Prins fuel selection switch.
3 +12V fuel switch	Red	
49 LIN fuel switch	yellow	
51 CAN-High	Blue-yellow	EOBD connector pin 6
70 CAN-Low	Blue	EOBD connector pin 14




Electrical connections

Check and measure the wiring in case of changes in the cars wiring colours.
Insulate not used wires.

LPG tank housing

Wire number / code	Wire colour	Connection
3-pole tank level connector 40 Ground tank gauge 12 Tank level in 11 + tank level supply	Brown Blue Red	Connect the 3-pole connector to the tank level sensor. Connector pin 1 Connector pin 2 Connector pin 3
1. 2-pole connector tank lock-off	Green-yellow Brown	Pump driver to lock-off power Pump driver to lock-off ground
2. 3-pole fusite	Red Brown -	1. Pump power 2. Pump ground 3. not used
3. 2-pole connector tank pump	Red 2.5mm ² Brown 2.5mm ²	Pump driver power Pump driver ground
4. 2-pole connector	Grey Green	Pump driver diagnose Pump driver control



Wiring tank relay 2 + tank relay 26 Ground tank relay +12V BATT fused +12V pump driver	Red Green-yellow Red 2.5mm ² Red 2.5mm ²	Pin 86 of the tank relay Pin 85 of the tank relay Pin 30 of the tank relay Pin 87 of the tank relay
--	---	--



Checklist after installation

1. Install the system fuses.
Turn on ignition.
Connect the Prins interface wire and run the Prins diagnosis program.
When working on the car, beware of moving and rotating parts in the engine compartment (even when the engine is not running !!).
2. When commissioning the LPG system, you must activate the AFC with the diagnosis software.
3. Check whether the program in the AFC matches with the car (dedicated engine set):
See "Identification" in the diagnosis program.
4. Check all components and connections for any LPG leakage, use a LPG leak detector device or a fluid detection like soap. Also check for petrol leakage. Make sure the solenoid valves are in open position.
No evidence of leakage is permitted.
Caution for moving and rotating parts in the engine compartment !
5. Use the diagnosis software to check again all input and output signals.
6. Check the system for error codes and solve these, if required.
Check the petrol MMS for EOBD error codes.
Place the protection connector back on the diagnose connector.
7. Make a test drive and check the cars drivability on LPG and petrol.

