

ALTERNATIVE
FUEL SYSTEMS

Prins

Quality, innovation and customer care, it's in our nature



Installation manual Dedicated PART 2/2

MANUFACTURER	Kia
TYPE	Carens
ENGINE DISPLACEMENT	1591
NUMBER OF VALVES	16
ENGINE CODE / NUMBER	G4FD
VEHICLE CATEGORIES	M
TRANSMISSION	MT
VERSION	Direct LiquiMax-2.0
PETROL ECU MANUFACTURER / CODE	Kefico MED 17.9.8 2BFB
HIGH PRESSURE PETROL PUMP	BOSCH-HDP-5-PE / 0261520.(081)/(082) TYPE5
HIGH PRESSURE PETROL INJECTOR	BOSCH-HDEV-5-1 / 0261500.(100)/(101)
MODEL YEAR:	3-2013
SYSTEM APPROVAL NUMBER (R115)	E4-115R-000004 / DLM-LPG 01
LOCATION SYSTEM STICKER	right side, centre door post
ENGINE SET NUMBER	349/070015/A
MANUAL NUMBER	076/2801000
DATE	2013-07-17

Copyright © Prins Autogassystemen B.V. 2013

Version 2012-11-02 D



TABLE OF CONTENTS

General instructions	2
Required equipment / tools / materials for installing a complete system	3
Vehicle check	3
Tightening moments	4
Direct LiquiMax	5
Overview Direct LiquiMax	6
Direct LiquiMax parts / approval numbers	7
DLM component location overview	8
Removal of the Bosch High Pressure Pump	9
Installation of the Bosch High Pressure Pump	10
High pressure pump installation	11
High pressure pump return	12
Preparation boost pump	13
Installation boost pump.	14
Connection of the fuel hose to the boost pump	15
Fuel Supply Unit	16
Fuel Return Unit	17
Mounting the Fuel Units	18
Lpg / petrol fuel lines	19
Supply hose – Return hose – Tank wiring	20
Hose routing 1	21
Hose routing 2	22
Valve protector pump reservoir 1	23
Valve protector pump reservoir 2	24
Mounting the AFC / fuse and relays	25
Wiring routing	26
Mounting the fuel selection switch	27
Electrical connections	28
Electrical connections	29
Electrical connections	30
Electrical connections	31
Electrical connections	32
Electrical connections	33
Checklist after installation	34

FOR EXPLANATION AND CIRCUIT DIAGRAMS SEE : INSTALLATION MANUAL GENERAL PART 1 / 2



General instructions

- The installation of the system shall be done in accordance with the installation manual provided by Prins Autogassystemen.
- This manual is based on Dutch regulations, always install the system in accordance to the local regulations.
- For an optimal functioning of the Direct LiquiMax system, maintain a clean and organized work environment during installation and maintenance to prevent pollution of the LPG components.
- Always download the "general manual 1/2 " from our website for basic instructions and diagrams.
- Always disconnect the battery when installing the lpg system. Make sure the ignition key is outside the car.
Be aware of central door locking, radio / telephone memory code, alarm system.
- Wear safety goggles when working on petrol filled system / connections (pressurized petrol)
- Do not place the main fuse into the fuse holder before having completed the installation of the system.
- The AFC has to be activated by means of the Prins diagnosis software.
- Never disconnect the AFC connector, unless you have removed the main fuse.
- When installing the wiring harness, ensure that it does not run near any of the ignition components.

Solder and insulate all electrical connections.

The wires in the loom are provided with numbers and text. The text on the wire explains the function of the wire.

The wire harness is not model specific, therefore it may be necessary to adjust the length of the wires.

Ensure maximum care is taken when connecting wiring.

Make professional joints using solder and shrink sleeve. Do not stretch the wiring harness.

- No component of the LPG-system shall be located within 100 mm of the exhaust or similar heat source, unless such components are adequately shielded against heat.
- If holes have to be drilled (wear safety glasses) for installing brackets, etc., the drilled holes must always be treated with an anti-corrosion agent, after the chips have been removed (especially when mounting a exterior filler into body work).
- After having completed the installation, check the whole system for lpg leakage; use a lpg leak detection device. Also check for leak of engine coolant, petrol and air.
- Fitting and maintenance is only allowed by Prins Autogassystemen selected LPG engineers.
- Failure to follow the instructions in this manual can result in a poor or non-working lpg installation or a dangerous situation.
- For maintenance instructions and filter registration see owner manual.
- Prins Autogassystemen is not responsible for any damages to people or objects as a result of changes to Prins products.
- Check our website regularly for diagrams, certificates, updates, info-bulletins and product information.

Register (warranty card) the system on the Prins warranty portal .



Required equipment / tools / materials for installing a complete system

- Complete workshop toolbox (wrenches, screwdrivers, cutters, pliers, ratchet, sockets)
- Car lift
- Portable computer : operating on Windows 98, W2000 or XP.
 - Internal memory : 16 Mb or more
 - Memory HD space : 5MB
 - Screen : 256 colours, advise colours 16 bits or more
 - Com port : 1 free COM port 1 or COM port 2 with a 9 or 25 pins connector
- Vehicle fuel system scan tool or OBD scan tool Prins (part nr. 099/99928)
- Exhaust gas analyser
- Multimeter
- Oscilloscope
- Prins diagnostic software
- Prins serial interface
- Torque wrench (5-50Nm)
- Torque wrench (200-250Nm)
- Portable light
- Assortment drill bits 4 to 12 mm
- Assortment cutters (ø 20, 30, 50, 70 mm)
- Portable drill or pneumatic drill
- Thread cutting device (male M6x1, M8x1, M10x1)
- Socket 46mm
- Air gun
- Vacuum cleaner
- Safety goggles
- Hot air gun
- Soldering iron, soldering tin
- Wire-stripping pliers
- Adhesive tape
- Adhesive sealant
- Thread locking compound
- Anti-corrosion agent / black body coating
- Gas leak detection device or foam leak spray
- Shrink sleeves
- Engine coolant

Vehicle check

- Check the vehicle drivability on petrol
- Check the fuel system for error codes (scan tool)
- Check if the catalytic converter is in good condition (exhaust gas analyzer)
- Check the condition of the ignition system (spark plugs, cables, coil)



Tightening moments

	Nm	SW
M 4 x 0,7	3.3	7
M 5 x 0,8	6.5	8
M 6 x 1,0	11.3	10
M 7 x 1,0	14.5	11
M 8 x 1	24.5	13
M 8 x 1,25	27.3	13
M 10 x 1	52	15-16-17
M 10 x 1,5	54	15-16-17
(filtered)Banjo bolt	10	14
Supply line connection	15	13
Fuel module Allen bolts	20	7
Filler hose connection	50	22

EXPLANATION OF SYMBOLS :




= IMPORTANT, CAUTION



= WEAR SAFETY GOGGLES




Direct LiquiMax



Overview Direct LiquiMax

overview Direct Liqui Max
















Direct LiquiMax parts / approval numbers

 <p>1st generation</p>  <p>2th generation</p>	 <p>1st generation</p>  <p>2th generation</p>
<p>Fuel Supply Unit : E4-67R-010269</p>	<p>Fuel Return Unit : E4-67R-010270 Pressure Sensor : E4-67R-010051</p>
	
<p>Boost pump</p>	<p>High Pressure Pump : E4-67R-010266 High Pressure Rail : E4-67R-010267 High Pressure Injectors : E4-67R-010309</p>
	 <p>XD-3 LPG</p>  <p>XD-4 LPG</p>
<p>Prins ECU : E4-67R-010098 E4-10R-030507</p>	<p>Fuel lines series XD : E4-67R-010247 XD3 E4-67R-010247 XD4</p>



DLM component location overview

FSU 		HPP pump 	AFC 
FRU 			Petrol ECU 
valve protector reservoir 			System relay 2x 
valve protector pump 			System Fuses 
	Boost pump 		
		<p>R115 approval sticker : Right side centre door post</p>	



Removal of the Bosch High Pressure Pump

-REMOVAL-

-WARNING-


In case of removing the high pressure fuel pump, high pressure fuel pipe, delivery pipe, there may be injury caused by leakage of the high pressure fuel.

Don't do any repair work right after engine stops (HOT engine).

- Turn the ignition switch OFF and disconnect the battery negative (-) cable.
- Wear safety goggles.
- Disconnect the fuel pressure regulator valve connector
- Disconnect the High Pressure fuel feed pipe (B)
- Remove the Low Pressure fuel pipe / hose (A).
- Remove the installation bolts (E), and then remove the high pressure fuel pump from the cylinder head assembly.

CAUTION:

Unscrew in turn the two bolts in small steps (0.5 turns). In case of fully unscrewing one of the two bolts with the other bolt installed, the housing surface of the cylinder head may break because of tension of the pump spring.



CAREFULLY store the removed petrol pump. Make sure no pollution can come into the pump.




Installation of the Bosch High Pressure Pump

-INSTALLATION-

Before installing the high pressure fuel pump, position the roller tappet (**B&C**) in the lowest position by rotating the crankshaft. Otherwise the installation bolts may be broken because of tension of the pump spring.

Apply engine oil to the O-ring (**A**) of the high pressure fuel pump, the roller tappet (**B**), and the protrusion (**C**). (roller tappet, only if removed from cylinder head)
Also apply engine oil to the groove on the location where the protrusion (**C**) is installed.



Installation bolts:

When tightening the installation bolts of the high pressure fuel pump, tighten and turn the bolts in small step (0.5 turns) after tightening them with hand-screwed torque.

High pressure fuel pump installation bolt: 12.8 ~ 14.7 N.m

Fuel pipe:

First hand-tighten the nut(s) fully until they are not fastened any more in order to have them inserted in place and then completely tighten to the specified torque using a torque wrench.

If not tightening the bolts or nuts in a straight line with the mating bolt holes or fittings, it may cause a fuel leak due to broken threads.

High pressure fuel pipe installation nut: 26.5 ~ 32.4 N.m


Installation is reverse of removal.



High pressure pump installation




Replace the high pressure pump for the adapted high pressure pump.
(Follow the workshop manual of the car)




High pressure pump return

Replace the high pressure pump for the adapted high pressure pump.
(Follow the workshop manual of the car)



Preparation boost pump




Replace connector and valve



spring washer




Drill up connector bracket



Remove hose and bracket



Re-locate wiring



install a spring washer and M6x18 nut



Install a new longer hose to the valve



Installation boost pump.

Connect the fuel hoses to the boost pump.




Filtered banjo

regular banjo



Connection of the fuel hose to the boost pump.



Connect the fuel hoses with an adapter to the boost pump.



Valve protector connection.




Fuel Supply Unit



Black filtered banjo will only be used on inlet connections !




Fuel Return Unit



Filter inside sensor banjo



Mounting the Fuel Units




treaded end M6x30




Spring washer and extended nut



original stud bolt with M6 nut




adapt engine cover




Lpg / petrol fuel lines


Hose	from	to	Length (cm)
1 XD-	Adapter original petrol hose	Petrol boost pump	40
2 XD-	Fuel supply unit	High pressure petrol pump	25
3 XD-	Petrol boost pump	Fuel supply unit	55
4 XD-	Fuel return unit	High pressure petrol pump	50



Install the fuel line using two bonded seal washers and banjo bolt :




Filtered banjo: (FSU supply inlets / boost pump inlet : black filtered banjo) :




Supply hose – Return hose – Tank wiring

Protect the supply- and return hose together with tank-wiring using the Ø16 split tube.
Mount the “hose assembly “ with clamps, with a maximum distance of 40cm.



Hose routing 1



Hose routing 2




Valve protector pump reservoir 1

Mounting the reservoir




Mounting valve protector




Remove the 2 M6 bolts met sensor place the bracket and sensor back



Valve protector pump reservoir 2




Remove the two M6 bolts with sensor.
Mount the pump bracket with the sensor on the original mounting points.
then insert the valve protection pump on the 3 mounting points




CAUTION CAUTION to make sure that the pipes installed right to quick release couplings go into.



Mounting the AFC / fuse and relays



Remove the battery mounting plate.




Install the battery mounting plate back.




Mounting point original m6 nut



Wiring routing



 Mount the switch.

Mounting the fuel selection switch




Drill a hole Ø8,2mm




Electrical connections

Check and measure the wiring in case of changes in the cars wiring colours.
Insulate not used wires.

Driver room

Wire number / code	Wire colour	Connection
3-pole micro connector 66 Ground fuel switch 3 +12V fuel switch 49 LIN fuel switch	Brown Red Yellow	Connect the 3-pole connector to the Prins fuel selection switch.
51 CAN-High	Blue-yellow	EOBD connector pin 6 white
70 CAN-Low	Blue	EOBD connector pin 14 brown
		



Electrical connections

Check and measure the wiring in case of changes in the cars wiring colours.
Insulate not used wires.

Wire number / code	Wire colour	Connection
		High pressure petrol sensor signal interruption Wire colour : White Wire location : Petrol ecu MK pin 20
18 Analog 1	Blue-red	Sensor side High pressure petrol sensor
25 Simulation 1	Green-grey	Petrol ecu side High pressure petrol sensor
1-32 MAIN GND ecu MAIN GROUND SENSE MAIN GND pump driver MAIN GND boost pump	Brown	Connect to the '-' of the battery (-31) ; use a ring terminal. Wire location : original ground M8 bolt
4 – 13 – 44 +12V BATT sense +12V BATT fused +12V BATT boost pump +12V BATT pump driver	Red	Connect to the '+' of the battery (+30) ; use a ring terminal. Do not place the fuse in the holder before having completed the installation of the lpg system. Wire location : Fuse box M8 nut.
17 Ad2 (Map)	Blue-black	Wire colour : Green/white Wire location : Petrol ecu MK pin 80
8 RPM	Purple-white	For measuring the engine speed signal. Wire colour : White Wire location : petrol ecu MK pin 65
15 T-ect	Grey	For measuring the engine coolant temperature. Wire colour : Yellow Wire location : Petrol ecu MA pin 23
7 +12V IGNITION	Grey - white	Make a connection to ignition + / contact + (+15). Do not place the fuse in the holder before having completed the installation of the lpg system. Wire colour : Pink Wire location : petrol ecu MK94 pin 29



Electrical connections

Check and measure the wiring in case of changes in the cars wiring colours.
Insulate not used wires.

Adaptive eco engine

5 pole super seal connector			
1	15+ ignition	Red	7 Grey-white 12 Volt ,15+
2	Ground	Brown	32 Brown LPG AFC ground
3	Signal injection	Purple	12 Blue LPG level sensor
4	Sign output cont. led	Yellow	Controlled (driver room) not used
5	Output ground by system is running	White	117 Yellow-grey LPG AFC (Output ground) 29 red is connected in the wiring harness with 117 <i>MAP connector: * cut off connector the blue red and brown</i> <i>The red and the brown Not used, insulate</i> 20 blue (Ad3)



Electrical connections

**Check and measure the wiring in case of changes in the cars wiring colours.
Insulate not used wires.**

6	Lambda1 WB	Orange	Not used
42	Lambda2 WB 10KΩ	Orange-white	Not used
19	Analog 4	Blue-white	Not used
121	Wake-up	Red-grey	Not used
10	Simulation 2	Green-black	Not used
23	Digital Simulation	Green-red	Not used
115	Digital input 4	Yellow-red	Not used
119	Digital input 2	Yellow-grey	Not used
97	Digital input 5	Yellow-orange	Not used
113	Digital input 6	Yellow-purple	Not used



Electrical connections

Check and measure the wiring in case of changes in the cars wiring colours.
Insulate not used wires.

Engine room

Wire number / code	Wire colour	Connection
<i>3-pole connector</i>		Connect the 3-pole connector to the Psys sensor positioned into the Fuel Return Unit.
35 C Ground pin A	Brown	Sensor wire pin A
9 +5V sensor pin B	Red	Sensor wire pin B
16 Psys pin C	Green	Sensor wire pin C
14 T-LPG	Grey	Not used, insulate.
<i>2-pole connector Boost Pump</i>		
106 + Lock-off Boost Pump	Red	Connect the 2-pole connector to the lock-off valve of the Boost Pump.
98 Ground lock-off	White-yellow	
<i>2-pole connector FSU</i>		
108 + Lock-off FSU	Red	Connect the 2-pole connector to the lock-off valve of the Fuel Supply Unit
100 Ground lock off	Pink-yellow	
<i>2-pole connector FRU</i>		
90 + Lock-off FRU	Red	Connect the 2-pole connector to the lock-off valve of the Fuel Return Unit
82 Ground lock off	Blue-yellow	
<i>4-pole diagnose connector</i>		Diagnose connector for service / diagnosis
46 Service TxD	Grey	Connector pin 1
65 Service RxD	Grey	Connector pin 2
68 C ground	Brown	Connector pin 4
<i>Boost pump relay</i>		
107 + relay boost pump	Red	Pin 86 of the boost pump relay
99 GND relay boost pump	Green-yellow	Pin 85 of the boost pump relay
+12V fused BATT	Red	Pin 30 of the boost pump relay
+12V Boost pump	Red	Pin 87 of the boost pump relay
<i>Wiring tank pump driver relay</i>		
2 + driver relay	Red	Pin 86 of the driver relay
26 Ground driver relay	Green-yellow	Pin 85 of the driver relay
+12V BATT fused	Red 2.5mm2	Pin 30 of the driver relay
+12V driver	Red 2.5mm2	Pin 87 of the driver relay



Electrical connections

Check and measure the wiring in case of changes in the cars wiring colours.
Insulate not used wires.

Lpg tank housing

Wire number / code	Wire colour	Connection
3-pole tank level connector 40 Ground tank gauge 12 Tank level in 11 + tank level supply	Brown Blue Red	Connect the 3-pole connector to the tank level sensor.
1. 2-pole connector tank lock-off	Green-yellow Brown	From tank pump driver From tank pump driver
2. 3-pole connector tank pump	Red 2.5mm ² Brown 2.5mm ²	From tank pump driver From tank pump driver
3. 2-pole connector driver	Red 2.5mm ² Brown 2.5mm ²	From tank pump relay 87 From main ground
4. 2-pole connector driver	Green Grey	From AFC pin 22 pwm From AFC pin 64 diagnose



Checklist after installation

1. Install the system fuses.
Turn on ignition.
Connect the Prins interface wire and run the Prins diagnosis program.
When working on the car, beware of moving and rotating parts in the engine compartment (even when the engine is not running !!).
2. When commissioning the LPG system, you must activate the AFC with the diagnosis software.
3. Check whether the program in the AFC matches with the car (dedicated engine set):
See "Identification" in the diagnosis program.
4. Check all components and connections for any LPG leakage, use a LPG leak detector device or a fluid detection like soap. Also check for petrol leakage. Make sure the solenoid valves are in open position.
No evidence of leakage is permitted.
Caution for moving and rotating parts in the engine compartment !
5. Use the diagnosis software to check again all input and output signals.
6. Check the system for error codes and solve these, if required.
Check the petrol MMS for EOBD error codes.
Place the protection connector back on the diagnose connector.
7. Make a test drive and check the cars drivability on LPG and petrol.

