




Important Note:

When driving on LPG please try to avoid running the Petrol tank under $\frac{1}{4}$, as the low-fuel indicator may chime occasionally due to the timed Petrol Gauge movement generated by the Petrol Gauge Reset Module.